Asus U50F-RBBAG05 Keyboard Replacement

This guide will show you how to remove/replace the keyboard of your Asus U5OF-RBBAG05

Written By: Kelly Greeling




INTRODUCTION

We are going to teach you how to remove/replace the Keyboard of your Asus U50F-RBBAG05.

TOOLS:


- Jimmy (1)
- iSesamo Opening Tool (1)

Step 1 — Battery



- First Step:
- Slide the tabs of the side of the battery back
- There is one on the left that can be locked into position (when it is showing red, it is unlocked)
- The tab on right you have to hold back while removing the battery.

Step 2






- The tab on right you have to hold back while removing the battery.
- Pull the battery out.

Step 3 — Keyboard









- Insert one of the pry tools under a top corner and the other tool under the side of the top corner(make sure to get under the metal of the keyboard, not just the first layer of plastic). Then pry the corner down and out from under the little overhang its sitting under.
- Next, slide the pry tool on the top over to the next overhang and insert the second tool on the other side. Push down and pry out the keyboard.
- Repeat all the way down to the opposite corner.


Step 4






- Once the keyboard is free, lift it up slightly and release the cable connection underneath.

Step 5





- Remove the keyboard completely.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-09-21 08:06:14 AM.